

## TYPICAL CONSTRUCTION WATER SOURCE FOR WATER TRUCKS

## **USE REQUIREMENTS:**

- A. Only one particular fire hydrant will be designated by Department of Public Works for use by construction.
- B. Only approved fire hydrant wrenches may be used on any City of Madera hydrant.
- C. Cap must be replaced on hydrant to protect threads between each load.
- D. Open and close hydrant valve slowly to prevent water hammer damage to water mains and laterals.
- E. Shut—off valve must be used and provided by contractor if more than ten loads of water are to be uttilized.
- F. Temporary cobstruction water meters will be set, relocated and monitored for water use by Public Works personnel only.
- G. Wtaer truck must be equipped with an approved air gap separation which shall be a minimum of twice the diameter of the supply line above the overflow of the water tank. All plumbing for air gap shall be attached to outside of tank.

NOTE: Anybody taking water from a City fire hydrant or other City water source without permission from City of Madera will be cited.

REF. & REV. MARCH 2005 CITY OF MADERA